

# RUCKUS One Online Help (index.html)

Search



## Cloning a Network

From the RUCKUS One web interface, you can clone a network.

Complete the following steps to clone a network.

1. From the navigation pane, click Wi-Fi > (and then)Wi-Fi Networks List.  
The Networks page is displayed.
2. Select the Network Name.

### Selecting a Network Name

Name	Description	Type	Venues	APs	Clients	VLAN	
<input type="radio"/> test0 (SSID: test1)		Open Network	1	0	0	VLAN-1	
<input type="radio"/> test-wlan-H		Pre-Shared Key (PSK)	0	0	0	VLAN-1	
<input type="radio"/> test-open-isolation		Open Network	0	0	0	VLAN-1	
<input type="radio"/> test-d		Pre-Shared Key (PSK)	2	0	0	VLAN-1	
<input type="radio"/> Test-ACX		Pre-Shared Key (PSK)	1	0	0	VLAN-1	
<input checked="" type="radio"/> TEST-1		Pre-Shared Key (PSK)	1	0	0	VLAN-1	

3. Click Clone at the top of the table.  
The Create New Network page is displayed. All the fields are updated with the selected network

settings information. Update the network settings as required. Refer to *Wireless Networks Overview (GUID-3B1FF432-398E-4567-A029-B07223EC2D0B.html)*.

4. Click Finish to save a new network settings.

800-73730-001 Rev D      29 April 2025  
© 2024 CommScope, Inc. All rights reserved.