RUCKUS One Online Help (index.html)

Search Q

Viewing Existing Networks

You can view a list of networks that exist in your RUCKUS One account.

From the navigation bar, click Wi-Fi > (and then)Wi-Fi Networks List. The Wireless Networks page displays a list of networks that you previously added, including the following information:

Note: If you have not added a network, the list will be empty. For instructions on adding a network, refer to *Wireless Networks Overview (GUID-3B1FF432-398E-4567-A029-B07223EC2D0B.html)*.

- Network: The name assigned to this network.
- Description: A brief description of the network.
- Type: The type of network representing the network security:
 - Pre-Shared Key (PSK)
 - Dynamic Pre-Shared Key (DPSK)
 - Enterprise AAA
 - Hotspot 2.0 Access
 - Captive Portal-Click-Through
 - Captive Portal-Self Sign in
 - Captive Portal-Host Approval
 - Cloudpath Captive Portal

1 of 2 5/28/25, 10:20 AM

- Captive Portal-Guest Pass
- Captive Portal-WISPr
- Open Network
- Venues: Shows the number of venues in which this network is currently being used. Click the number to view venue details.
- APs: Shows the number of APs (across all venues) that are currently associated with this network. Click the number to view AP details.
- Clients: Shows the number of clients (across all venues) that are currently associated with this network. Click the number to view client details.
- VLAN: Shows the VLAN ID that is assigned to the network.

800-73730-001 Rev D 29 April 2025

© 2024 CommScope, Inc. All rights reserved.

2 of 2 5/28/25, 10:20 AM